

• BOTTOM VIEW (DISPLAY BOARD)

to FUNC board J1

J3	
5	1
KST2	KRT0
KST3	KRT1
6	2

to PLL unit J1

J9	
19	1
PCK	14DT
PDAT	PST4
43DT	14UL
14UL	43UL
GND	GND
NC	NC
NC	BFST
14V	14V
+9V	NC
-5V	NC
20	2

to JACK board J2


J5			
1	PHIN	GND	2
	SSPO	PHG	
5	MSPO	GND	6

to VR-A board J1

J2			
1	+5V	NC	2
	MSVR	MAVR	
5	NC	GND	6

to MIC board J2

J6	
9	1
MICE	AFO
GND	MSQLS
PTT	MIUD
10	+9V
	NC
	2



J4	
4	1
GND	A
	B
	+5V

to MAIN SENSOR

J11			
1	+5V	NC	2
	SSVR	SAVR	
5	NC	GND	6

to VR-B board J1

J10			
6	GND	NC	5
	RIVR	SFVR	
2	NC	+5V	1

to RIT board J1

J8	
1	29
GND	CIVE
	PTT1
	MIUD
	SEND
	DASH
	SBSY
	KDS
	AGRM
	SQLM
	SMLM
	CTCM
	BEEP
	CENS
	AGRS
	SQLS
	SMLS
	MSC
	OVDV
	TONC
	GND
2	30

to MAIN unit J1151

J7	
1	29
GND	INTM
	RXS
	MCK
	NC
	ETON
	VOXL
	NC
	PDAT
	FORL
	12PS
	12DS
	12UL
	14PV
	POWS
	12PV
	GND
2	30

to MAIN unit J1101

J12	
1	3
GND	FANV
	NC

to FAN

J14	
1	7
MSPO	
SSPO	
PHG	
14V	
HV	
MIC	
MICE	

to MAIN unit J1251, J1201